



- 1. Prongs
- 2. Coring Blade
- 3. Peeling Blade
- 4. Peeling Blade Wingnut
- 5. Spindle
- 6. Spindle Release Lever
- 7. Handle
- 8. Suction Clamp Lever
- 9. Peeling Blade Lock
- 10. Coring Blade Wingnut
- 11. Slicing Blade



CAUTION: BLADES ARE VERY SHARP. AVOID DIRECT CONTACT WITH FINGERS AND HANDS. KEEP OUT OF REACH OF CHILDREN.

This terrific tool, with its strong suction base and sharp blades, peels, cores and slices apples rapidly with a simple turn of the handle. Versatile adjustments allow you to make perfect 1/4" slices in one easy operation, greatly reducing the preparation time for many dishes. You may also choose to use this tool to peel only, or core and slice without peeling. ***For best results use only firm, symmetrical fruit or potatoes. Please read through all the instructions to obtain the best performance from your peeler.***

CARING FOR THE APPLIANCE

HAND WASH ONLY. Lubricate the moving parts with vegetable oil to keep free from corrosion, which can cause sticking.

GETTING STARTED

Set the peeler on an even, smooth countertop or cutting board. Hold the peeler firmly at the round base and move the suction clamp lever (8) to the lock position. Make sure the clamp is securely suctioned to the surface before proceeding.

Make any of the following adjustments in preparation for use:

- Remove the protective cap from the prongs (1).
- Slide the spindle (5) back as far as it will go by pressing the spring-loaded spindle release lever (6) and pulling the spindle by the handle (7). **NOTE:** The prongs should pass through the round coring blade (2). If the prongs cannot pass through the coring blade, loosen the coring blade wingnut (10) and **carefully** adjust the coring blade unit (2)(11) until the prongs can pass through the center. Retighten the wingnut. **Use caution! Do NOT hold onto the slicing blade side (11) of the coring blade unit to adjust.**

PEEL, CORE AND SLICE

- Center the core of the apple in front of the prongs (1) and push the stem end securely onto the prongs.
- Turn the handle (7) to begin the process.

NOTE: Adjust the peel thickness by loosening the peeling blade wingnut (4) and sliding the peeling blade (3) forward or back. Re-tighten the wingnut.

- Continue turning the handle (7) until the apple has completely cleared the coring blade unit (2)(11). Remove the sliced apple by pulling it away. Remove the core by pulling it off the prongs (1).

PEEL ONLY

- Slide the spindle (5) back until the prongs (1) pass through the coring blade unit (2)(11).
- Loosen the coring blade wingnut (10) and rotate the coring blade unit (2)(11) out of the way or remove it completely. **Use caution! Do NOT hold onto the slicing blade side (11) of the coring blade unit to adjust.**

CORE AND SLICE ONLY

- Hold the spring-loaded peeling blade assembly (3) away from the spindle (5).
- Flip the peeling blade lock (9) into the locked position.

