


# Instructions For Wire Replacement Green & White Marble Cheese Slicer



Unscrew the handle. Loop the wire over the threaded end of the handle. Fit the threaded end of the handle into the opening in the channel and slide onto the arm. Align the wire with the groove in the channel. Slide the channel front to back on the arm to center the wire in the marble groove. Once aligned, tighten the handle to secure.



Slide the arm out enough to remove the wire. Loop the new wire over the end of the arm and slide the arm back in.

