


How To Change The Potato Ricer Press Plates



Squeeze the two tabs toward each other and slide the collar up and out. Insert desired size plate and slide the collar in until it clicks into place.